

ECODESIGN INFORMATION

Applies to non-residential ventilation units (NRVU)

According to Regulation EU No 1253/2014 of the European Commission, implementing Directive 2009/125/CE of European Parliament

SODECA, S.L.U.

www.sodeca.com

c) Typology
d) Type of drive
e) Type of HRS

g) Nominal flowrate
h) Effective electric power input
i) SFPint

k) Nominal external pressure
l) Internal pressure drop of ventilation components
m) Internal pressure drop of non-ventilation components

327/2011
o1) Max. Internal leakage index
o2) Max. External leakage index
p) Energy performance of the filters

r) LWA radiated

b)	c)	d)	e)	f)	g)	h)	i)	j)	k)	l)	m)	n)	o1)	o2)	p)	q)	r)	ERP
				%	m ³ /s	kW	W/m ³ /s	m/s	Pa	Pa	Pa	Pa	%	%			dBA	
UFRX-315-0.5 G4+F6	NRVU / UVU	Velocitat variable	Cap		1.374	0.754	230	2.10	77	56		47.9		0.3	G4: G; F6: F	Veure manual	74	2018
UFRX-315-0.75 G4+F6	NRVU / UVU	Velocitat variable	Cap		1.454	0.976	230	2.22	120	63		53.2		0.3	G4: G; F6: F	Veure manual	72	2018
UFRX-315-1 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.597	0.982	230	2.44	126	75		59.3		0.2	G4: G; F6: F	Veure manual	74	2018
UFRX-315-1.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.678	1.208	230	2.56	177	83		61.2		0.2	G4: G; F6: F	Veure manual	77	2018
UFRX-315-2 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.743	1.497	230	2.66	246	90		62.5		0.2	G4: G; F6: F	Veure manual	79	2018
UFRX-315-3 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.812	1.783	230	2.76	318	97		63.1		0.2	G4: G; F6: F	Veure manual	82	2018
UFRX-355-0.75 G4+F6	NRVU / UVU	Velocitat variable	Cap		1.814	0.812	230	1.48	38	41		50.8		0.4	G4: G; F6: F	Veure manual	71	2018
UFRX-355-1 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		1.961	0.789	230	1.59	36	47		59.0		0.3	G4: G; F6: F	Veure manual	73	2018
UFRX-355-1.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		2.169	1.141	230	1.76	75	58		60.8		0.3	G4: G; F6: F	Veure manual	76	2018
UFRX-355-2 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		2.361	1.580	230	1.92	131	69		62.2		0.3	G4: G; F6: F	Veure manual	78	2018
UFRX-355-3 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		2.527	2.165	230	2.05	215	79		62.8		0.3	G4: G; F6: F	Veure manual	80	2018
UFRX-355-4 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		2.739	3.284	230	2.23	390	93		63.3		0.2	G4: G; F6: F	Veure manual	83	2018
UFRX-355-5.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		2.935	4.555	230	2.39	611	106		65.0		0.2	G4: G; F6: F	Veure manual	85	2018
UFRX-400-1.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		2.353	0.661	230	1.91	4	19		60.4		0.3	G4: G; F6: F	Veure manual	78	2018
UFRX-400-2 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		2.538	0.825	230	2.06	9	23		61.7		0.3	G4: G; F6: F	Veure manual	80	2018
UFRX-400-3 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		2.896	1.284	230	2.36	27	29		62.5		0.2	G4: G; F6: F	Veure manual	83	2018
UFRX-400-4 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		3.945	3.956	230	3.21	184	55		63.0		0.2	G4: G; F6: F	Veure manual	85	2018
UFRX-400-5.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		4.245	5.048	230	3.45	264	63		64.7		0.2	G4: G; F6: F	Veure manual	88	2018
UFRX-400-7.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		4.510	6.531	230	3.67	379	72		67.0		0.1	G4: G; F6: F	Veure manual	90	2018
UFRX-450-2 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		2.726	0.719	230	1.38	6	42		61.3		0.3	G4: G; F6: F	Veure manual	82	2018
UFRX-450-3 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		3.173	1.282	230	1.61	43	56		62.0		0.3	G4: G; F6: F	Veure manual	85	2018
UFRX-450-4 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		4.057	3.838	230	2.06	287	92		62.6		0.2	G4: G; F6: F	Veure manual	87	2018
UFRX-450-5.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		4.320	5.371	230	2.19	460	104		64.3		0.2	G4: G; F6: F	Veure manual	90	2018
UFRX-450-7.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		4.550	7.138	230	2.31	675	116		66.6		0.2	G4: G; F6: F	Veure manual	92	2018
UFRX-450-10 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		4.710	9.379	230	2.39	951	124		65.2		0.2	G4: G; F6: F	Veure manual	94	2018
UFRX-500-2 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		5.072	3.253	230	2.57	97	54		63.3		0.2	G4: G; F6: F	Veure manual	83	2018
UFRX-500-3 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		5.387	4.069	230	2.73	139	61		64.0		0.2	G4: G; F6: F	Veure manual	86	2018
UFRX-500-4 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		5.237	3.604	230	2.66	115	58		64.7		0.2	G4: G; F6: F	Veure manual	88	2018
UFRX-500-5.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		5.552	4.421	230	2.82	159	65		66.3		0.2	G4: G; F6: F	Veure manual	90	2018
UFRX-500-7.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		6.141	6.386	230	3.12	279	79		68.6		0.2	G4: G; F6: F	Veure manual	92	2018
UFRX-500-10 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		6.660	8.922	230	3.38	450	93		69.7		0.1	G4: G; F6: F	Veure manual	95	2018
UFRX-500-15 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		7.114	12.027	230	3.61	675	106		69.7		0.1	G4: G; F6: F	Veure manual	98	2018
UFRX-500-20 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		7.288	14.030	230	3.70	822	112		69.2		0.1	G4: G; F6: F	Veure manual	99	2018
UFRX-560-3 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		4.817	2.108	230	1.65	51	57		63.6		0.2	G4: G; F6: F	Veure manual	72	2018
UFRX-560-4 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		5.232	2.878	230	1.79	93	67		64.3		0.2	G4: G; F6: F	Veure manual	75	2018
UFRX-560-5.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		5.948	4.954	230	2.04	226	86		66.0		0.2	G4: G; F6: F	Veure manual	77	2018
UFRX-560-7.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		6.535	7.668	230	2.24	427	104		68.4		0.2	G4: G; F6: F	Veure manual	79	2018
UFRX-560-10 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		6.780	9.278	230	2.32	554	112		69.2		0.2	G4: G; F6: F	Veure manual	81	2018
UFRX-560-15 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		7.160	13.111	230	2.45	869	125		69.2		0.2	G4: G; F6: F	Veure manual	84	2018
UFRX-560-20 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		7.376	17.954	230	2.53	1270	133		69.1		0.2	G4: G; F6: F	Veure manual	87	2018
UFRX-560-25 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		7.524	20.226	230	2.58	1474	138		69.7		0.2	G4: G; F6: F	Veure manual	89	2018
UFRX-560-30 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		7.492	20.406	230	2.57	1482	137		69.7		0.2	G4: G; F6: F	Veure manual	89	2018
UFRX-630-3 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		6.622	2.602	230	2.27	32	45		60.7		0.2	G4: G; F6: F	Veure manual	74	2018
UFRX-630-4 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		7.924	5.136	230	2.71	118	65		61.3		0.2	G4: G; F6: F	Veure manual	77	2018
UFRX-630-5.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		8.503	6.814	230	2.91	185	75		62.8		0.1	G4: G; F6: F	Veure manual	79	2018
UFRX-630-7.5 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		9.048	8.700	230	3.10	269	85		65.0		0.1	G4: G; F6: F	Veure manual	81	2018
UFRX-630-10 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		9.528	10.978	230	3.26	376	94		66.1		0.1	G4: G; F6: F	Veure manual	84	2018
UFRX-630-15 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		10.316	16.660	230	3.53	661	110		66.1		0.1	G4: G; F6: F	Veure manual	86	2018
UFRX-630-20 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		10.589	20.321	230	3.63	850	116		66.0		0.1	G4: G; F6: F	Veure manual	89	2018
UFRX-630-25 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		10.655	19.911	230	3.65	835	117		67.1		0.1	G4: G; F6: F	Veure manual	90	2018
UFRX-630-30 G4+F6 IE3	NRVU / UVU	Velocitat variable	Cap		10.622	20.114	230	3.64	842	116		66.6		0.1	G4: G; F6: F	Veure manual	92	2018
UFRX-315-0.5 F6+F8	NRVU / UVU	Velocitat variable	Cap		1.451	0.730	230	2.21	51	43		47.9		0.3	F6: F; F8: A	Veure manual	74	2018
UFRX-315-0.75 F6+F8	NRVU / UVU	Velocitat variable	Cap		1.550	0.947	230	2.36	81	49		53.2		0.3	F6: F; F8: A	Veure manual	72	2018
UFRX-315-1 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.695	0.951	230	2.58	84	59		59.3		0.2	F6: F; F8: A	Veure manual	74	2018
UFRX-315-1.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.794	1.173	230	2.74	121	66		61.2		0.2	F6: F; F8: A	Veure manual	77	2018
UFRX-315-2 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.880	1.460	230	2.87	171	72		62.5		0.2	F6: F; F8: A	Veure manual	79	2018
UFRX-315-3 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.967	1.746	230	3.00	226	79		63.1		0.2	F6: F; F8: A	Veure manual	82	2018
UFRX-355-0.75 F6+F8	NRVU / UVU	Velocitat variable	Cap		1.849	0.801	230	1.50	30	35		50.8		0.3	F6: F; F8: A	Veure manual	71	2018
UFRX-355-1 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		1.996	0.778	230	1.62	28	40		59.0		0.3	F6: F; F8: A	Veure manual	73	2018

ECODESIGN INFORMATION

Applies to non-residential ventilation units (NRVU)

According to Regulation EU No 1253/2014 of the European Commission, implementing Directive 2009/125/CE of European Parliament

SODECA, S.L.U.

www.sodeca.com

				%	m³/s	kW	W/m³/s	m/s	Pa	Pa	Pa	%	%	%			dBA	
UFRX-355-1.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		2.217	1.124	230	1.80	60	50		60.8		0.3	F6: F; F8: A	Veure manual	76	2018
UFRX-355-2 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		2.424	1.556	230	1.97	106	59		62.2		0.3	F6: F; F8: A	Veure manual	78	2018
UFRX-355-3 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		2.609	2.134	230	2.12	176	69		62.8		0.2	F6: F; F8: A	Veure manual	80	2018
UFRX-355-4 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		2.852	3.246	230	2.32	325	82		63.3		0.2	F6: F; F8: A	Veure manual	83	2018
UFRX-355-5.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		3.079	4.521	230	2.50	516	96		65.0		0.2	F6: F; F8: A	Veure manual	85	2018
UFRX-400-1.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		2.397	0.646	230	1.95	1	7		60.4		0.3	F6: F; F8: A	Veure manual	78	2018
UFRX-400-2 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		2.593	0.804	230	2.11	3	9		61.7		0.2	F6: F; F8: A	Veure manual	80	2018
UFRX-400-3 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		2.980	1.241	230	2.42	9	11		62.5		0.2	F6: F; F8: A	Veure manual	83	2018
UFRX-400-4 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		4.197	3.734	230	3.41	65	23		63.0		0.2	F6: F; F8: A	Veure manual	85	2018
UFRX-400-5.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		4.563	4.742	230	3.71	95	27		64.7		0.1	F6: F; F8: A	Veure manual	88	2018
UFRX-400-7.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		4.916	6.107	230	4.00	137	31		67.0		0.1	F6: F; F8: A	Veure manual	90	2018
UFRX-450-2 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		2.760	0.709	230	1.40	4	35		61.3		0.3	F6: F; F8: A	Veure manual	82	2018
UFRX-450-3 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		3.231	1.260	230	1.64	33	48		62.0		0.3	F6: F; F8: A	Veure manual	85	2018
UFRX-450-4 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		4.212	3.773	230	2.14	236	81		62.6		0.2	F6: F; F8: A	Veure manual	87	2018
UFRX-450-5.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		4.522	5.302	230	2.29	385	94		64.3		0.2	F6: F; F8: A	Veure manual	90	2018
UFRX-450-7.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		4.800	7.084	230	2.44	573	106		66.6		0.2	F6: F; F8: A	Veure manual	92	2018
UFRX-450-10 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		5.008	9.374	230	2.54	822	115		67.4		0.2	F6: F; F8: A	Veure manual	94	2018
UFRX-500-2 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		5.283	3.239	230	2.68	51	30		63.3		0.2	F6: F; F8: A	Veure manual	83	2018
UFRX-500-3 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		5.650	4.048	230	2.87	74	35		64.0		0.2	F6: F; F8: A	Veure manual	86	2018
UFRX-500-4 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		5.471	3.587	230	2.78	60	33		64.7		0.2	F6: F; F8: A	Veure manual	88	2018
UFRX-500-5.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		5.838	4.398	230	2.96	85	37		66.3		0.2	F6: F; F8: A	Veure manual	90	2018
UFRX-500-7.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		6.549	6.348	230	3.32	150	47		68.6		0.1	F6: F; F8: A	Veure manual	92	2018
UFRX-500-10 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		7.221	8.866	230	3.66	247	57		69.7		0.1	F6: F; F8: A	Veure manual	95	2018
UFRX-500-15 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		7.855	11.956	230	3.99	378	67		69.7		0.1	F6: F; F8: A	Veure manual	98	2018
UFRX-500-20 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		8.142	13.956	230	4.13	467	72		69.2		0.1	F6: F; F8: A	Veure manual	99	2018
UFRX-560-3 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		4.906	2.093	230	1.68	41	48		63.6		0.2	F6: F; F8: A	Veure manual	72	2018
UFRX-560-4 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		5.352	2.859	230	1.83	76	57		64.3		0.2	F6: F; F8: A	Veure manual	75	2018
UFRX-560-5.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		6.147	4.938	230	2.11	188	75		66.0		0.2	F6: F; F8: A	Veure manual	77	2018
UFRX-560-7.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		6.826	7.694	230	2.34	363	93		68.4		0.2	F6: F; F8: A	Veure manual	79	2018
UFRX-560-10 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		7.119	9.347	230	2.44	476	101		69.2		0.2	F6: F; F8: A	Veure manual	81	2018
UFRX-560-15 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		7.600	13.329	230	2.60	764	115		69.2		0.2	F6: F; F8: A	Veure manual	84	2018
UFRX-560-20 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		7.914	18.435	230	2.71	1141	125		69.1		0.2	F6: F; F8: A	Veure manual	87	2018
UFRX-560-25 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		8.104	20.840	230	2.78	1335	131		69.7		0.1	F6: F; F8: A	Veure manual	89	2018
UFRX-560-30 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		8.073	21.035	230	2.77	1344	130		69.7		0.1	F6: F; F8: A	Veure manual	89	2018
UFRX-630-3 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		6.842	2.539	230	2.34	17	28		60.7		0.2	F6: F; F8: A	Veure manual	74	2018
UFRX-630-4 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		8.351	4.995	230	2.86	66	41		61.3		0.1	F6: F; F8: A	Veure manual	77	2018
UFRX-630-5.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		9.061	6.631	230	3.10	106	49		62.8		0.1	F6: F; F8: A	Veure manual	79	2018
UFRX-630-7.5 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		9.749	8.486	230	3.34	157	56		65.0		0.1	F6: F; F8: A	Veure manual	81	2018
UFRX-630-10 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		10.394	10.753	230	3.56	224	64		66.1		0.1	F6: F; F8: A	Veure manual	84	2018
UFRX-630-15 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		11.557	16.550	230	3.96	414	79		66.1		0.1	F6: F; F8: A	Veure manual	86	2018
UFRX-630-20 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		12.043	20.404	230	4.13	547	86		66.0		0.1	F6: F; F8: A	Veure manual	89	2018
UFRX-630-25 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		12.089	19.957	230	4.14	535	87		67.1		0.1	F6: F; F8: A	Veure manual	90	2018
UFRX-630-30 F6+F8 IE3	NRVU / UVU	Velocitat variable	Cap		12.067	20.178	230	4.13	541	86		66.6		0.1	F6: F; F8: A	Veure manual	92	2018
UFRX-315-0.5 F7+F9	NRVU / UVU	Velocitat variable	Cap		1.412	0.743	230	2.15	64	50		47.9		0.3	F7: A; F9: A	Veure manual	74	2018
UFRX-315-0.75 F7+F9	NRVU / UVU	Velocitat variable	Cap		1.502	0.964	230	2.29	101	56		53.2		0.3	F7: A; F9: A	Veure manual	72	2018
UFRX-315-1 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.646	0.968	230	2.51	105	68		59.3		0.2	F7: A; F9: A	Veure manual	74	2018
UFRX-315-1.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.735	1.193	230	2.65	149	75		61.2		0.2	F7: A; F9: A	Veure manual	77	2018
UFRX-315-2 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.810	1.483	230	2.76	209	82		62.5		0.2	F7: A; F9: A	Veure manual	79	2018
UFRX-315-3 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.887	1.770	230	2.88	273	89		63.1		0.2	F7: A; F9: A	Veure manual	82	2018
UFRX-355-0.75 F7+F9	NRVU / UVU	Velocitat variable	Cap		1.831	0.806	230	1.49	34	38		50.8		0.4	F7: A; F9: A	Veure manual	71	2018
UFRX-355-1 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		1.979	0.784	230	1.61	32	44		59.0		0.3	F7: A; F9: A	Veure manual	73	2018
UFRX-355-1.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		2.193	1.133	230	1.78	67	54		60.8		0.3	F7: A; F9: A	Veure manual	76	2018
UFRX-355-2 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		2.393	1.569	230	1.95	119	64		62.2		0.3	F7: A; F9: A	Veure manual	78	2018
UFRX-355-3 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		2.568	2.150	230	2.09	195	74		62.8		0.3	F7: A; F9: A	Veure manual	80	2018
UFRX-355-4 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		2.795	3.267	230	2.27	357	88		63.3		0.2	F7: A; F9: A	Veure manual	83	2018
UFRX-355-5.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		3.007	4.541	230	2.45	564	101		65.0		0.2	F7: A; F9: A	Veure manual	85	2018
UFRX-400-1.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		2.376	0.653	230	1.93	3	13		60.4		0.3	F7: A; F9: A	Veure manual	78	2018
UFRX-400-2 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		2.566	0.815	230	2.09	6	16		61.7		0.3	F7: A; F9: A	Veure manual	80	2018
UFRX-400-3 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		2.938	1.263	230	2.39	18	21		62.5		0.2	F7: A; F9: A	Veure manual	83	2018
UFRX-400-4 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		4.073	3.853	230	3.31	123	40		63.0		0.2	F7: A; F9: A	Veure manual	85	2018
UFRX-400-5.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		4.406	4.909	230	3.58	178	46		64.7		0.1	F7: A; F9: A	Veure manual	88	2018
UFRX-400-7.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		4.715	6.344	230	3.83	258	53		67.0		0.1	F7: A; F9: A	Veure manual	90	2018
UFRX-450-2 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		2.743	0.714	230	1.39	5	38		61.3		0.3	F7: A; F9: A	Veure manual	82	2018
UFRX-450-3 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		3.202	1.271	230	1.62	38	52		62.0		0.3	F7: A; F9: A	Veure manual	85	2018
UFRX-450-4 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap		4.134	3.808	230	2.10	261	87		62.6		0.2	F7: A; F9: A	Veure manual	87	2018

ECODESIGN INFORMATION

Applies to non-residential ventilation units (NRVU)

According to Regulation EU No 1253/2014 of the European Commission, implementing Directive 2009/125/CE of European Parliament

SODECA, S.L.U.

www.sodeca.com

				%	m³/s	kW	W/m³/s	m/s	Pa	Pa	Pa	%	%	%			dB(A)	
UFRX-450-5.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	4.421	5.341	230	2.24	423	99		64.3	0.2	F7: A; F9: A	Veure manual	90	2018		
UFRX-450-7.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	4.674	7.118	230	2.37	625	111		66.6	0.2	F7: A; F9: A	Veure manual	92	2018		
UFRX-450-10 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	4.857	9.387	230	2.46	889	120		67.4	0.2	F7: A; F9: A	Veure manual	94	2018		
UFRX-500-2 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	4.473	3.279	230	2.27	223	102		63.3	0.2	F7: A; F9: A	Veure manual	83	2018		
UFRX-500-3 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	4.652	4.096	230	2.36	311	110		64.0	0.2	F7: A; F9: A	Veure manual	86	2018		
UFRX-500-4 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	4.578	3.631	230	2.32	261	107		64.7	0.2	F7: A; F9: A	Veure manual	88	2018		
UFRX-500-5.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	4.759	4.448	230	2.41	353	115		66.3	0.2	F7: A; F9: A	Veure manual	90	2018		
UFRX-500-7.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	5.048	6.391	230	2.56	584	130		68.6	0.2	F7: A; F9: A	Veure manual	92	2018		
UFRX-500-10 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	5.227	8.839	230	2.65	883	139		69.7	0.2	F7: A; F9: A	Veure manual	95	2018		
UFRX-500-15 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	5.330	11.738	230	2.70	1240	145		69.7	0.2	F7: A; F9: A	Veure manual	98	2018		
UFRX-500-20 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	5.317	13.546	230	2.70	1450	144		69.2	0.2	F7: A; F9: A	Veure manual	99	2018		
UFRX-560-3 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	4.862	2.101	230	1.67	46	52		63.6	0.2	F7: A; F9: A	Veure manual	72	2018		
UFRX-560-4 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	5.293	2.869	230	1.81	84	62		64.3	0.2	F7: A; F9: A	Veure manual	75	2018		
UFRX-560-5.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	6.048	4.948	230	2.07	207	81		66.0	0.2	F7: A; F9: A	Veure manual	77	2018		
UFRX-560-7.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	6.680	7.686	230	2.29	395	99		68.4	0.2	F7: A; F9: A	Veure manual	79	2018		
UFRX-560-10 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	6.949	9.319	230	2.38	516	107		69.2	0.2	F7: A; F9: A	Veure manual	81	2018		
UFRX-560-15 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	7.377	13.229	230	2.53	819	120		69.2	0.2	F7: A; F9: A	Veure manual	84	2018		
UFRX-560-20 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	7.639	18.203	230	2.62	1209	129		69.1	0.2	F7: A; F9: A	Veure manual	87	2018		
UFRX-560-25 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	7.807	20.541	230	2.67	1408	135		69.7	0.2	F7: A; F9: A	Veure manual	89	2018		
UFRX-560-30 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	7.775	20.728	230	2.66	1417	134		69.7	0.2	F7: A; F9: A	Veure manual	89	2018		
UFRX-630-3 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	6.035	2.696	230	2.07	76	81		60.7	0.2	F7: A; F9: A	Veure manual	74	2018		
UFRX-630-4 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	6.865	5.216	230	2.35	240	104		61.3	0.2	F7: A; F9: A	Veure manual	77	2018		
UFRX-630-5.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	7.181	6.807	230	2.46	356	114		62.8	0.2	F7: A; F9: A	Veure manual	79	2018		
UFRX-630-7.5 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	7.466	8.536	230	2.56	490	123		65.0	0.2	F7: A; F9: A	Veure manual	81	2018		
UFRX-630-10 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	7.677	10.552	230	2.63	649	130		66.1	0.2	F7: A; F9: A	Veure manual	84	2018		
UFRX-630-15 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	7.943	15.330	230	2.72	1032	140		66.1	0.2	F7: A; F9: A	Veure manual	86	2018		
UFRX-630-20 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	7.967	18.274	230	2.73	1261	141		66.0	0.2	F7: A; F9: A	Veure manual	89	2018		
UFRX-630-25 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	8.045	17.968	230	2.76	1248	143		67.1	0.1	F7: A; F9: A	Veure manual	90	2018		
UFRX-630-30 F7+F9 IE3	NRVU / UVU	Velocitat variable	Cap	8.006	18.120	230	2.74	1254	142		66.6	0.2	F7: A; F9: A	Veure manual	92	2018		